



Termination Bar T-96™

Installation Instructions

Surface Preparation

Place York's Termination Bar T-96 at the top edge of the material so that the material guide lip is sitting on top of the flashing. Use stainless steel screws to attach the termination bar to the substrate. Fill the sealant lip with a sealant that is compatible with adjoining materials, such as York's UniverSeal US-100, and avoid using sealants that contain high levels of solvents or plasticizers.

